



# PROXIMITY ADAPTER KIT (HMK-M30-PROXY-01)

NOTE: \*PROXIMITY SWITCH (SW1400) IS NOT INCLUDED  
\*POTTING OF THE WIRING IN THE BACK IS OPTIONAL



## PROCEDURE:



Insert Wires (7801041120-01) on proximity switch (SW1400).



Assemble the proximity switch and the proximity switch main housing (BR2917).



Insert other end of wires on the deutsch connector (CH1179) and attach the wedge (CA1156).



Mount the deutsch connector on proximity switch main housing.



Attach the proximity switch plate (BR2919) using bolt M4X12 dome head socket (HW1971).



BR2917 7801041120-01 CH1179 CA1156 BR2919 HW1971